




## It is very important that the 'Cool Down Procedure' is completed prior to cleaning of the oven.

Note - The correct PPE must be worn . Do not use a caustic cleaner on the oven as this will cause permanent damage to the oven.





CLEAN



2. Place the supplied 'Cool Down' metal tray, filled with ice or water into the oven. Press the green tick to start the cool down process. The door can be left open to speed up the cool down, but it will blow hot air into the kitchen.






3. Cool down4. Remove the completed.Cool Down pan.



5. Remove the Cook plate and wash by hand.




6. Spray Merrychef cleaner onto a sponge and wipe over the cavity and door, avoiding the door seal and internal top plate.



7. Use a green nylon pad to scrub the oven cavity Avoiding the door seal and internal top plate.





8. Use a clean cloth to wash & dry off the oven including the top plate.



9. Use a clean cloth to apply the Merrychef protector avoiding the top plate, cook plate, fan housing and door seal





11. Turn oven OFF.

10. Follow the prompt to remove & clean the front filter. Open the cover at the base of the oven, remove filter and wash in warm soapy water. Replace when completed.